

FOR FIELD KITCHEN K120 AND PANTRY P120

Congratulations on your new **Kanz Outdoors Field Kitchen**.
We wish you years of enjoyment wherever you roam.

OVERVIEW



1. Top lid (removable) with lid stay. Can be use as serving tray or converted into horizontal space with accessory.
2. Side shelves (optional), store inside stove compartment during transport.
3. Stove platform (shown with Partner Steel Co. stove).
4. Compartment for mugs (6 KANZ Mugs fit here).
5. Silverware drawer.
6. Fold down table held by steel lanyard, can be dropped down.
7. Fuel access hole (optional, per order).
8. Main cookware compartment.
9. Vertical space for plates and cutting board. The cutting board doubles as a wedge to keep the plates in place.

* Cookware shown of full furnished K120PF version

SETUP ON OPTIONAL LEGS



- 1.) Place the closed Field Kitchen on firm ground. Grab a handle and lift it up on one side. Insert two legs. Try to prevent dirt from entering the leg receivers.



- 2.) Raise the kitchen carefully, balancing it on the two previously inserted legs. Insert the remaining legs.

- 3.) Place the unit at a spot of your choice on firm, level ground. This is important to prevent the pots and pans to slide off the stove. Alter the ground by wedging pieces of wood or rock under the unsupported legs to avoid wobbling. It is very important for the safety of operation that the Kitchen stands level and stable!
- 4.) Open the top lid and secure it with the lid stay.
- 5.) Fold down the table.
- 6.) Deploy the optional side shelves to create extra horizontal working surfaces.
- 7.) Connect the stove to its fuel source.
- 8.) Your kitchen is ready!

- ❖ When the kitchen is employed on the long leg set, the fold down table provides a convenient working surface for a sitting person, whereas the side shelf become a working surface for a standing person.

PROTECTION

After usage, clean up all kitchen items and close the kitchen. Protect it from rain, snow and moisture. The optional padded cordura cover protects it from the elements.

ACCESSORIES



Dry Bag



Hanging Straps



Padded Cover



Wall Mounts

Visit our website www.kanzoutdoors.com for more information.



CARE & MAINTENANCE

KANZ Outdoors LLC manufactures all of our products to meet our high standards. To maintain the beauty and functioning of the Field Kitchen products, inspect and clean them regularly. Use a damp cloth and medium duty household cleaners to remove dirt and fatty residues. Do not use abrasive wipes or scrapers, since they will permanently change the surface appearance. Wipe surfaces dry immediately after.

Inspect for loose rivets and damaged parts. Repair immediately to prevent the product from malfunctioning or encountering more damage.

Even the outdoor polyurethane clear coat will suffer under strong constant sunlight. To fix cracked or peeled off paint, sand area lightly and apply a new coat of clear outdoor quality polyurethane.

Please contact customerservice@kanzoutdoors.com for more help on this.

NOTE

Avoid constant exposure to a very humid environment, since it might even cause the quality birch plywood to degrade. Long exposure to ultraviolet light will cause some yellowing of the wood. This is normal and in most cases desirable.

SAFETY

Do not use the kitchen with an outdoor stove, like the Partner Steel Co. or Coleman stoves in an enclosed space such as a camper, tent, car or home.

Never leave the kitchen unattended with a burning stove. **Observe all precautions from the stove manufacturer!**

Use the kitchen only when employed on stable ground to avoid spillage of hot liquids.

Keep small children and pets at a distance. Explain the precautions to them.

When not in use extinguish all burners and close the front panel to prevent small animals from entering the unit.

Disconnect any fuel source during transport in a vehicle, vessel or pack animal.

WARRANTY

Products manufactured or branded by KANZ Outdoors LLC are covered under warranty, to the original owner for the lifetime of the product, if products were used within the intended focus. We cover all defects in material and workmanship. Extended usage will leave its marks on the products. This is considered normal wear and tear and is not covered by the warranty.

For all other products sold through KANZ Outdoors channels, the product manufacturers warranty applies. However, we will be glad to help providing the necessary information.

FOR YOUR SAFETY

If you smell gas:

1. Do not attempt to light appliance.
2. Extinguish any open flame.
3. Disconnect from fuel supply.

Do not store or use gasoline or other liquids with flammable vapors in the vicinity of this or any other appliance.

CARBON MONOXIDE HAZARD

- Stoves can produce carbon monoxide which has no odor.
- Using it in an enclosed space can kill you.
- Never use this appliance in an unventilated area such as a camper, tent, car or home.

BURN HAZARD

- Never leave stove unattended when hot or in use.
- Keep out of reach of children.

NOTES



KANZ Outdoors LLC
P.O. Box 280388
Northridge, CA 91328-0388